

Aluminum ball mount
Use and care instructions

| MODEL | DROP | RISE | HOLE SIZE | SHANK SIZE |
|-----------|------|------|-----------|------------|
| DT-BM4200 | 2" | 1" | 1" | 2" |
| DT-BM4400 | 4" | 3" | | |
| DT-BM4600 | 6" | 5" | | |
| DT-BM5200 | 2" | 1" | 1-1/4" | |
| DT-BM5400 | 4" | 3" | | |
| DT-BM5600 | 6" | 5" | | |

| MAX TRAILER WT. LB | MAX TONGUE WT. LB |
|--------------------|-------------------|
| 10,000 | 1,000 |

Congratulations on your purchase of a new Fastway® FLASH™ aluminum ball mount (BM). Read these instructions thoroughly to become familiar with proper set up and maintenance procedures. This will ensure your FLASH ball mount will give you maximum performance, and years of service.

Keep these instructions in a safe place as a reference for future information, or access them online at fastwaytrailer.com/manuals.

Important Safety Information

Failure to follow all safety warnings may result in severe injury or death.

⚠ WARNING

- Read, understand, and follow all safety warnings, setup, use, and maintenance instructions of your trailer, tow vehicle, and hitching equipment before installing your FLASH ball mount or towing your trailer.
- Never cut, weld, grind, bend, heat, or modify ball mount components in any way.
- It is the driver's responsibility to properly install and adjust equipment and adjust driving habits to match towing conditions. The driver is responsible for their own safety and the safety of passengers.
- Never exceed the specified weight ratings for the trailer, tow vehicle, receiver hitch, ball mount, hitch ball, or any other towing equipment.
- Always load the trailer correctly. Follow trailer and tow vehicle manufacturer's recommendations for placement and quantity of cargo. Tongue weight should be between 10% -15% of Gross Trailer Weight (GTW).
- Always use a hitch ball size that correctly matches your trailer coupler size and make sure it is coupled securely before towing.
- Do not impact the ball mount on the ground. Do not back into things with your ball mount or attached trailer (i.e. loading docks, curb and gutter, etc.). If your ball mount has been impacted in any way, thoroughly inspect it for damage before towing, and if it is bent or damaged DO NOT tow; replace it.
- Do not unlock the ball mount from the receiver while the ball mount is under load from an attached trailer.
- Check all towing hardware for damage and wear before each trip. Replace damaged or worn hardware before towing.
- Check your keys before use to make sure they are in good working order and that the safety locator tab at the front of the key barrel is intact.



Hitch ball not included



Optional 2" locking hitch pin part# 86-00-3050

Please register your product. See the warranty information on back.

Made in the USA

⚠️ WARNING

- Always use a hitch ball with the correct diameter threaded shaft to fit the hole in the ball mount.
- Always use a hitch ball with a rating that equals or exceeds the Gross Trailer Weight.

⚠️ CAUTION

- Never use the ball mount to tow a vehicle with a chain or tow strap, or as an anchor for pulling or winching.
- Always tow with a ball mount set to the correct height for the trailer being towed.
- Do not tow your trailer on excessively rough roads.
- Do not tow your trailer through profound ditches, dips, or swales.
- Replace all worn, faded, or unreadable warning stickers on the ball mount immediately.

Instructions for use

INSTALL THE HITCH BALL

FLASH ball mounts come with either a 1" or 1-1/4" diameter hole for the hitch ball attachment. Install a hitch ball that has the correct diameter threaded shank to fit the hole in your ball mount. Make sure to torque the hitch ball nut to the specifications given by the hitch ball manufacturer.

Before you tow, grease the hitch ball. Use a good quality multi-purpose or bearing grease. This protects the hitch ball and the inside of your trailer coupler. The chrome coating on the ball is not covered under the ball mount warranty.

Use a 5/8" diameter hitch pin to secure the ball mount in the receiver of your tow vehicle.

To help protect your ball mount from theft, we recommend using the Fastway locking hitch pin, part # 86-00-3050 for 2" receivers, and part # 86-00-3160 for 2.5" receivers.

Care and maintenance

Proper attention and care to your FLASH locking ball mount will help it provide years of trouble free service.

Regularly (at least monthly) remove your ball mount from the receiver and make sure the receiver is not rusting and corroding around the ball mount. This is especially important in areas where salt and other chemicals are used on roadways to melt snow and ice. Remove your FLASH ball mount and store it inside the tow vehicle instead of in the receiver during winter months when it will be exposed to the sand and snow melt used on winter roads.

CLEANING - As necessary, wipe away dirt and grime with a soft cloth. When cleaning the ball mount surfaces, **DO NOT** use degreasers or harsh cleaners - simple mild soap and water is best for aluminum. Aluminum rim cleaner and a good automobile wax will help maintain the polished luster of the aluminum.

Visit our YouTube channel for a detailed video of the FLASH BM ball mount.



youtube.com/fastwaytrailer



facebook.com/fastwaytrailer



twitter.com/fastwaytrailer



google.com/+fastwaytrailerproducts

Limited 1 year warranty

Do not return this product to the retailer.

For warranty claims or customer support contact Fastway Trailer Products directly weekdays 8:00 AM - 5:00 PM Mountain time at 877-523-9103 or by email at support@fastwaytrailer.com.

Fastway Trailer Products warrants the FLASH BM ball mount, excluding chrome and corrosion, against latent defects in materials and workmanship under normal use and service, ordinary wear and tear is excepted, to the original owner for a period of 1 year from the first date of purchase at retail up to the value of its original purchase price. If this product is latently defective it will be replaced or repaired when a proper return authorization is obtained and the product is returned with transportation charges prepaid to Fastway Trailer Products.

Fastway Trailer Products shall not be required to replace or repair any products damaged as a result of improper installation, alteration, unreasonable use, or improper maintenance including, without limitation, loading the product beyond the factory rated load capacity.

This warranty does not include labor charges nor does it include transportation charges for returning the product to the consumer. To the extent allowed by law, Fastway Trailer Products shall not be liable for any incidental, consequential, or any other damages including, without limitation, breach of any implied warranty, merchantability, or fitness for a particular purpose of any Fastway product. In no event shall Fastway Trailer Products be liable for any damages other than the replacement or repair of the affected part. Authorization and warranty procedure may be obtained by calling Fastway Trailer Products customer support at 877-523-9103.

Great products make towing faster and easier. Get more info at fastwaytrailer.com.

ZIP™

BREAKAWAY
CABLE



Protect your fingers from loose sharp wire, and provide a safer and more effective connection to your trailer.

FLIP™

AUTOMATIC
JACK FOOT



Save time and effort by extending your trailer jack by six inches, eliminating fifty cranks both up and down.

ONESTEP™

STABILIZING WHEEL CHOCK



Virtually eliminates unwanted wheel movement providing the most stability for your trailer.

CHAIN UP™



The fastest and easiest way to keep your safety chains from dragging.